



* PARCEL SIZE IS MEASURED BASED ON LATEST LAND SURVEY.

EAST PARCEL DENSITY CALCULATION AND PARKING COUNT (POST ROW DEDICATION)

* PARCEL SIZE IS MEASURED BASED ON LATEST LAND SURVEY.

All dimensions must be taken and checked before starting work. No dimension should be measured on printed plans. The content of this document is an intellectual property of IDEA Architects. No total or partial use can be made without the written permission of its author.